

Cessna 150, A150, 152, & A152 Serial Numbers

1959	150	1701 – 17683	
1960	150	17684-17999, 59001-59018	
1961	150A	15059019-15059350	
1962	150B	15059351-15059700	
1963	150C	15059701-15060087	
1964	150D	15060088-15060772	
1965	150E	15060773-15061532	
1966	150F	15061533-15064532	
1967	150G	15064533-15067198	
1968	150H	15067199-15069308	
1969	150J	15069309-15071128	
1970	150K	15071129-15072003	A1500001-A1500226
1971	150L	15072004-15072628	A1500227-A1500276
1972	150L	15072629-15073658	A1500277-A1500342
1973	150L	15073659-15074850	A1500343-A1500429
1974	150L	15074851-15075781	A1500430-A1500523
1975	150M	15075782-15077005	A1500524-A1500609
1976	150M	15077006-15078505	A1500610-A1500684
1977	150M	15078506-15079405	A1500685-A1500734
1978	152	15279406-15282031	A1520735-A1520808
1979	152	15282032-15283591	A1520809-A1520878
1980	152	15283592-15284541	A1520879-A1520943
1981	152	15284542-15285161	A1520944-A1520983
1982	152	15285162-15285594	A1520984-A1521014
1983	152	15285595-15285833	A1521015-A1521025
1984	152	15285834-15285939	A1521026-A1521027
1985	152	15285940-15286033	A1521028-A1521049